

## NOTES:

- 1. REPEAT COURSES A AND B TO FULL HEIGHT OF WALL.
- 2. AFFIX ALL UNITS WITH CONSTRUCTION-GRADE ADHESIVE.
- 3. REFER TO CAPPING DETAIL FOR CORNER CAP INSTALLATION OPTIONS.
- 4. WHERE POSSIBLE, BEGIN CONSTRUCTION AT CORNER AND WORK OUTWARD.



Anchor Wall Engineering, LLC 5959 Baker Road, Suite 390 Minnetonka, MN 55345 These graphic representations are intended for preliminary design purposes only and are not to be used for construction without the signature of a registered professional engineer.

© 2011 Anchor Wall Engineering, LLC ® and TM Anchor Wall Systems, Inc.

Drawn By:	Drawing Title:
AWE	Brisa <sup>TM</sup> Freestanding Wall System
Date:	90-Degree Corner Construction
2///2011	
Scale:	Project Information: Typical Details For

1/2"=1'-0"

Typical Details For Freestanding Walls