



STEP 1 - PLACE REINFORCEMENT TO WITHIN 1 INCH OF WALL FACE SO LITTLE OR NO OVERLAP OCCURS IN THE RADIUS AREA. IF OVERLAP OCCURS, PLACE 2 TO 3 INCHES OF SAND BETWEEN THE REINFORCEMENT LAYERS.

STEP 2 - LAY THE NEXT COURSE OF BLOCK. MAKE A MARK ON THE BACK OF THE BLOCKS IN THE AREAS THAT ARE NOT REINFORCED. BACKFILL AND COMPACT THAT COURSE.

STEP 3 - PLACE REINFORCEMENT IN THE AREAS WHERE THE MARKS SHOW GAPS IN THE LOWER REINFORCEMENT PATTERN. CONTINUE NORMAL WALL CONSTRUCTION, REPEATING THESE STEPS AS NEEDED.

NOTES:

1. MINIMUM RADIUS INFORMATION:
 - A. INSIDE RADIUS: 8 FEET TO FACE (AT BASE OF WALL)
 - B. OUTSIDE RADIUS: 4 FEET TO BACK (AT TOP OF WALL)
2. GRID LENGTH (L) PER DESIGN
3. REPEAT STEPS AS NEEDED TO FULL HEIGHT OF WALL



Anchor Wall Engineering, LLC
5959 Baker Road, Suite 390
Minnetonka, MN 55345

These graphic representations are intended for preliminary design purposes only and are not to be used for construction without the signature of a registered professional engineer.

© 2011 Anchor Wall Engineering, LLC
® and ™ Anchor Wall Systems, Inc.

Drawn By: AWE
Date: 1/28/2011
Scale: 1/2"=1'-0"

Drawing Title:
Project Information:

**Brisa™ Retaining Wall Systems
Curve Details**

Typical Details For
Conventional Retaining Walls