


PERMEABLE PAVER

INSTALLATION

The installation instructions and illustrations shown are a basic overview of paver and wall installation methods. Because installation methods vary per product, please refer to the Basalite product specific installation guide, the Standard ICPI installation method, ICPI.org or visit contact us at basalite.com.



1. Excavate unsuitable, unstable or unconsolidated subgrade material and compact the area in accordance to ICPI guidelines. Backfill and level Sub-base with No. 2 aggregate 2-1/2" crushed. Backfill and level base layer with No. 57 aggregate 3/4" crushed. The joint material and the foundation (paver bed, subbase, subgrade) must be permeable. 60mm thick pavers may be used in pedestrian applications.

2. Install edge restraint using concrete curb, concrete toe or edging.

3. Place bedding course of No. 8 aggregate 3/8" leveled to grade.

4. Install Pavers in closed assembly with spacer on stone for water drainage. Fill joints with gravel. Where required, cut stones with an approved cutter to fit accurately.

5. Tamp pavers with mechanical vibrator, uniformly level, true to grade and free of movement. **TIP: If your pavers have a textured surface, use a compactor**

with a urethane pad or place a sheet of geotextile or old low-pile carpet, over the surface before compacting to reduce scuffing.

6. Fill voids in joints by sweeping dry ASTM No. 8, 89 or 9 stones.