


TYPICAL PAVER INSTALLATION

The installation instructions and illustrations shown are a basic overview of paver and wall installation methods. Because installation methods vary per product, please refer to the Basalite product specific installation guide, the Standard ICPI installation method, ICPI.org or visit contact us at basalite.com.



1. Excavate unsuitable, unstable or unconsolidated subgrade material and compact the area which has been cleared. Backfill and level with dense graded aggregate suitable for base material (typically 3"-6" for pedestrian/light vehicular traffic and 8"-10" for driveway applications), or as otherwise directed by site engineer/architect/landscape architect.

2. Install edge restraint using concrete curb, concrete toe or edging.

3. Place bedding course of sharp,

normal-weight screening or concrete sand to a uniform depth of approximately 1" leveled to grade. Add two inches of bedding when installing for vehicle traffic.

4. Install Basalite Pavers hand tight with joints approximately 1/8". Where required, cut stones with an approved cutter to fit accurately.

5. Tamp pavers with mechanical vibrator, uniformly level, true to grade and free of movement.

TIP: If your pavers have a textured surface, use a compactor with a urethane pad or place a sheet of geotextile or old low-pile carpet, over the surface before compacting to reduce scuffing.

6. Fill voids in joints by sweeping dry, fine, sharp sand over pavers.

Installation of Mod 7 pavers require a roll compactor only